



Rezo 10



Rezo 15



Rezo 20



Rezo 30



Rezo 50



Rezo 60



Rezo 110AW



Rezo 120AW



Rezo 140AW



Rezo 160AW



Rezo 170AW

















Rezo TLZ 10



Rezo TLZ 20

	Rezo 10	Rezo 15	Rezo 20	Rezo 30	Rezo 50	Rezo 60	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20
<b>Aifa</b>													
DC-8330i													
<b>Argus</b>													
DC-6340													
<b>BenQ</b>													
C840													
DC C1050													
DC C740i													
DC C750													
DC C820													
DC C850													
DC E100													
DC E800													
DSC X800													

		 Rezo 10	 Rezo 15	 Rezo 20	 Rezo 30	 Rezo 50	 Rezo 60	 Rezo 110AW	 Rezo 120AW	 Rezo 140AW	 Rezo 160AW	 Rezo 170AW	 Rezo TLZ 10	 Rezo TLZ 20
Canon	MD-110 DV													
	DC21/DC22													
	DC210/230													
	DC410/DC420													
	DC50													
	Digital IXUS 80		•											
	EOS 30D w/compact zoom									•		•	•	
	EOS 40D w/compact zoom									•				
	EOS 50D/w compact zoom										•			
	EOS 5D/5D Mk II w/compact zoom											•		
	EOS Digital Rebel T1i/500D w/compact zoom									•				•
	EOS Digital Rebel XS/1000D w/compact zoom									•				•
	EOS Digital Rebel XSi/450D w/compact zoom									•				•
	EOS Digital Rebel Xti/400D w/ compact zoom									•	•			•
	IXUS 70		•											
	IXY Digital 820IS		•											
	MD110 DV								•					
	MD160								•					
	MV850i								•					
	MV930/940/950/960								•					
	MVX330i								•					
	MVX430								•					
	MVX450/460								•					
	PowerShot A1000 IS				•									
	PowerShot A1100 IS				•									
	PowerShot A2000 IS				•									
	PowerShot A2100 IS				•									
	PowerShot A470						•							
	PowerShot A480					•								
	PowerShot A570 IS						•							
	PowerShot A580						•							
	PowerShot A590 IS						•							
	PowerShot A650 IS							•						
	PowerShot A720 IS							•						
	PowerShot D10						•							
	PowerShot E1					•								
	PowerShot G10							•						
	PowerShot G9							•						
	PowerShot S5 IS								•					
	PowerShot SD1000/IXUS 70		•	•										
	PowerShot SD1100 IS/IXUS 80	•	•											
	PowerShot SD1200 IS	•	•											
	PowerShot SD770/IXUS 85	•	•											
	PowerShot SD780 IS	•	•											
	PowerShot SD790 IS/IXUS 90 IS	•	•											
PowerShot SD850 IS/IXUS 950 IS	•	•												
PowerShot SD870 IS/IXUS 860 IS	•	•												
PowerShot SD880 IS/IXUS 870 IS	•	•												
PowerShot SD890 IS/IXUS 970 IS	•	•												
PowerShot SD950 IS/Digital IXUS 960 IS	•	•												
PowerShot SD960 IS	•	•												
PowerShot SD970 IS	•	•												
PowerShot SD990 IS/IXUS 980 IS	•	•												
PowerShot SX1 IS								•						
PowerShot SX10 IS								•						
PowerShot SX100 IS								•						
PowerShot SX110 IS						•								
PowerShot SX200 IS						•								
PowerShot TX-1		•												
SD1200 IS	•	•												
SD850IS/Ixus 950IS	•	•												
Vixia HF S10/S100								•						
Vixia HF20/HF200								•						
Vixia HG20/HG21								•						
ZR800								•						
ZR830/850								•						
ZR900								•						
ZR930								•						
ZR950								•						
ZR960								•						
Casio	EXILIM EX-FC100			•										
	EXILIM EX-FH20			•				•					•	
	EXILIM EX-FS10			•										
	EXILIM EX-S10	•	•											
	EXILIM EX-S12	•	•											
	EXILIM EX-S5			•										
	EXILIM EX-S880			•										
	EXILIM EX-V7/V8			•										
	EXILIM EX-Z100			•										
	EXILIM EX-Z1080			•										
	EXILIM EX-Z11			•										
	EXILIM EX-Z200			•										
	EXILIM EX-Z250			•										
	EXILIM EX-Z270			•										
	EXILIM EX-Z29			•										
EXILIM EX-Z400			•											

\*Availability may vary depending on country and location

		 Rezo 10	 Rezo 15	 Rezo 20	 Rezo 30	 Rezo 50	 Rezo 60	 Rezo 110AW	 Rezo 120AW	 Rezo 140AW	 Rezo 160AW	 Rezo 170AW	 Rezo TLZ 10	 Rezo TLZ 20
EXILIM EX-Z80		.	.	.										
EXILIM EX-Z85			.											
EXILIM EX-Z850			.											
EXILIM EX-Z9			.											
EXILIM Pro EX-F1							.						.	
DXG	110			.		.								
	202V													
	305V				.									
	568				.									
	572V					.								






























	Rezo 10	Rezo 15	Rezo 20	Rezo 30	Rezo 50	Rezo 60	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20
<b>Fuji</b>													
FinePix A100/A150		•											
FinePix A820/A825/A900			•										
FinePix A850		•											
FinePix A920			•										
FinePix F100fd			•										
FinePix F200EXR			•										
FinePix F40fd			•										
FinePix F47fd			•										
FinePix F480			•										
FinePix F50fd/F60fd		•											
FinePix IS 1												•	
FinePix IS Pro w/compact zoom											•		
FinePix J10/J20		•											
FinePix J100/J110W/J120W/J150W		•											
FinePix J12/J50		•											
FinePix S1000fd					•								
FinePix S100FS					•			•					
FinePix S1500					•			•					
FinePix S2000HD								•					
FinePix S5 Pro w/compact zoom								•				•	
FinePix S5800								•				•	
FinePix S700								•				•	
FinePix S8000fd								•				•	
FinePix S8100fd								•				•	
FinePix Z10fd/Z100fd/Z200fd	•							•					
FinePix Z20fd	•												
FinePix Z30fd		•											
FinePix Z33		•											
FinePix Z5fd	•												
<b>GE</b>													
A730				•									
A735/A835		•											
E1035/E1235				•									
E1050		•											
E840S				•									
G2/G3		•											
H855				•									
<b>Hitachi</b>													
DZ-BD70A								•					
DZ-BD7HA								•					
DZ-GX5020A/5080A								•					
DZ-MV380								•					
DZ-MV550/MV580								•					
DZ-MV780A								•					
HS300A/500A								•					
<b>HP</b>													
Photosmart E337				•									
Photosmart E427		•											
Photosmart M437		•											
Photosmart M447		•											
Photosmart M537		•											
Photosmart M547		•											
Photosmart M627		•											
Photosmart M637		•											
Photosmart M737		•											
Photosmart Mz67		•											
Photosmart R742		•											
Photosmart R837				•									
Photosmart R847				•									
Photosmart R937				•									
<b>JVC</b>													
Everio GZ-MG130								•					
Everio GZ-MG145								•					
Everio GZ-MG155/255								•					
Everio GZ-MG555U								•					
Everio GZ-MG575								•					
Everio GZ-X900								•					
GR-D250				•				•					
GR-D73US						•		•					
GR-D750/770/796						•		•					
GR-D850/870						•		•					
GR-DA30						•		•					
GZ-HD300/HD320						•		•					
GZ-HD7/HD7U						•		•			•		
GZ-MG130						•		•					
GZ-MG255						•		•					
GZ-MG630/MG670/MG680						•		•					
<b>Kodak</b>													
EasyShare C180		•											
EasyShare C513		•											
EasyShare C603				•									
EasyShare C613				•									
EasyShare C653				•									
EasyShare C703				•									
EasyShare C713		•											
EasyShare C763		•											
EasyShare C913		•											
EasyShare M1033		•											
EasyShare M1063		•											
EasyShare M1073 IS		•											
EasyShare M1093 IS				•									

\*Availability may vary depending on country and location

	 Rezo 10	 Rezo 15	 Rezo 20	 Rezo 30	 Rezo 50	 Rezo 60	 Rezo 110AW	 Rezo 120AW	 Rezo 140AW	 Rezo 160AW	 Rezo 170AW	 Rezo TLZ 10	 Rezo TLZ 20
EasyShare M320/M340			•										
EasyShare M380			•										
EasyShare M753/M853			•										
EasyShare M763/M863	•	•											
EasyShare M893 IS		•											
EasyShare Picture Viewer	•												
EasyShare V1073/V1273		•											
EasyShare V1233/V1253			•										
EasyShare V1285			•										
EasyShare V803/V1003			•										
EasyShare Z1012 IS						•							
EasyShare Z1015 IS						•							
EasyShare Z1275			•										
EasyShare Z1285			•										
EasyShare Z1485 IS					•								
EasyShare Z712 IS							•						
EasyShare Z812 IS												•	
EasyShare Z8612 IS												•	
EasyShare Z885			•										
EasyShare Z915					•								
EasyShare Z980												•	
Zi6					•								
Zx1			•										














		 Rezo 10	 Rezo 15	 Rezo 20	 Rezo 30	 Rezo 50	 Rezo 60	 Rezo 110AW	 Rezo 120AW	 Rezo 140AW	 Rezo 160AW	 Rezo 170AW	 Rezo TLZ 10	 Rezo TLZ 20
<b>Leica</b>	C-Lux 1		•	•										
	C-Lux 3		•											
	Digilux 3							•						
	D-Lux 3					•								
	D-Lux 4					•								
	M8 w/compact zoom										•			
V-Lux 1										•				
<b>Minox</b>	DC 7022		•											
	DC-6033 WP						•							
	DC-8011		•											
<b>Mustek</b>	DV-4500						•							
	GSmart D35						•							
	MDC-6500z						•							
<b>Nikon</b>	Coolpix 8800							•					•	
	Coolpix L100							•						
	Coolpix L14/L15			•										
	Coolpix L16/L18			•										
	Coolpix L19/L20			•										
	Coolpix P5000/P5100					•								
	Coolpix P60					•								
	Coolpix P6000 GPS						•							
	Coolpix P80												•	
	Coolpix P90												•	
	Coolpix S200		•											
	Coolpix S202		•											
	Coolpix S210		•											
	Coolpix S220		•											
	Coolpix S51/S51c		•											
	Coolpix S510		•											
	Coolpix S52		•											
	Coolpix S520		•											
	Coolpix S52c		•											
	Coolpix S550		•											
	Coolpix S560		•											
	Coolpix S60		•											
	Coolpix S600		•											
	Coolpix S610/S610c		•											
	Coolpix S620		•											
	Coolpix S630				•									
	Coolpix S700		•											
	Coolpix S710		•											
	D200 w/compact zoom												•	
	D50 w/compact zoom													•
	D5000 w/compact zoom										•			•
	D60 w/compact zoom								•					•
D70 w/compact zoom										•		•	•	
D80 w/compact zoom										•		•	•	
D90 w/compact zoom										•		•	•	















		 Rezo 10	 Rezo 15	 Rezo 20	 Rezo 30	 Rezo 50	 Rezo 60	 Rezo 110AW	 Rezo 120AW	 Rezo 140AW	 Rezo 160AW	 Rezo 170AW	 Rezo TLZ 10	 Rezo TLZ 20	
Olympus	E3 w/compact zoom														
	E30 w/compact zoom														
	E410 w/compact zoom														
	E-420 w/compact zoom														
	E-420 w/pancake 25mm lens														
	E-510/E520 w/compact zoom														
	E-620/w/compact zoom														
	FE-190														
	FE-20														
	FE-25														
	FE-280														
	FE-290														
	FE-300														
	FE-3000/3010														
	FE-310														
	FE-320														
	FE-340														
	FE-350														
	FE-360														
	FE-370														
	FE-45														
	FE-5000/5010														
	Mju 1040														
	Mju 1050SW														
	Mju 1060														
	SP-565UZ														
	SP-570UZ														
	SP-590UZ														
	Stylus 1010/1020														
	Stylus 1030SW														
	Stylus 1040														
	Stylus 1050SW														
Stylus 1200/Mju Digital 1200															
Stylus 550WP/Mju 550WP															
Stylus 7000/Mju 7000															
Stylus 770SW															
Stylus 780															
Stylus 790SW/Mju 790SW															
Stylus 830/Mju Digital 830															
Stylus 840															
Stylus 850SW															
Stylus Tough 6000/Mju 6000															
Stylus Tough 8000/Mju 8000															
X835															

													
<b>Panasonic</b>													
HDC-DX1													
HDC-FX5													
HDC-HS20													
HDC-HS250													
HDC-HS300													
HDC-HS9													
HDC-SD1/SD3													
HDC-SD100/HS100													
HDC-SD20/TM20													
HDC-SD9													
HDC-TM300													
Lumix DMC-FX07													
Lumix DMC-FS12/FS62													
Lumix DMC-FS15													
Lumix DMC-FS20													
Lumix DMC-FS25													
Lumix DMC-FS3/FS5													
Lumix DMC-FS42													
Lumix DMC-FS6													
Lumix DMC-FS7													
Lumix DMC-FX100													
Lumix DMC-FX150													
Lumix DMC-FX33													
Lumix DMC-FX35													
Lumix DMC-FX37													
Lumix DMC-FX40/FX48													
Lumix DMC-FX500													
Lumix DMC-FX55													
Lumix DMC-FX550/FX580													
Lumix DMC-FZ18													
Lumix DMC-FZ28													
Lumix DMC-FZ50													
Lumix DMC-G1/GH1 w/compact zoom													
Lumix DMC-L10 w/compact zoom													
Lumix DMC-LS60/LS75													
Lumix DMC-LS80													
Lumix DMC-L585													
Lumix DMC-LX3													
Lumix DMC-LZ10													
Lumix DMC-LZ6/LZ7													
Lumix DMC-LZ8													
Lumix DMC-TS1/FT1													
Lumix DMC-TZ2/TZ3													
Lumix DMC-TZ4/TZ5													
Lumix DMC-TZ50													
Lumix DMC-TZ6/ZS1													
Lumix DMC-TZ7/ZS3													
NV-GS1/GS4/GS5													
NV-GS11B/15B													
NV-GS23B/33B/55B													
NV-GS230													
NV-GS60													
NV-GX7													
PV-GS150													
PV-GS180													
PV-GS31													
PV-GS320													
PV-GS35													
PV-GS39													
PV-GS55													
PV-GS80/85													
PV-GS90													
SDR-H18													
SDR-H20/H250													
SDR-H40/H60													
SDR-S10P1													
SDR-S15													
SDR-S150													
SDR-S7													
SDR-SW20													
SDR-SW21													
VDR-D160													
VDR-D250													
VDR-M53													
VDR-N75													
<b>Pentax</b>													
*ist D w/compact zoom													
*ist DL w/compact zoom													
*ist DS w/compact zoom													
*st DS 2 w/compact zoom													
K100D w/compact zoom													
K110D w/compact zoom													
K2000/K-m w/compact zoom													
K200D w/compact zoom													
K20D w/compact zoom													
K-7 w/compact zoom													
Optio A30													

\*Availability may vary depending on country and location



lowepro														
		Rezo 10	Rezo 15	Rezo 20	Rezo 30	Rezo 50	Rezo 60	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20
Optio A40			•											
Optio E40			•											
Optio E50			•											
Optio E60				•										
Optio E70			•											
Optio L30			•											
Optio M30				•										
Optio M40				•										
Optio M50/M60			•											
Optio P70			•											
Optio S10			•											
Optio S12			•											
Optio T30				•										
Optio V10			•											
Optio V20			•											
Optio W30				•										
Optio W60				•										
Optio Z10			•											
X70													•	
<b>Polaroid</b>			•											
A310			•											
i533P			•											
i631			•											
i633				•										
i733			•											
i832W			•											
<b>Pure Digital</b>			•											
Flip Mino/Mino HD			•											
Flip Video			•											
Flip Video Ultra			•											
<b>RCA</b>							•							
CDS4100							•							
CDS6300							•							
<b>Ricoh</b>														
Caplio 500SE														
Caplio GX100					•									
Caplio GX200					•									
Caplio RR770				•										
CX1				•										
G600														
GR Digital II					•									
R10				•										
R50				•										
R8				•										

		 Rezo 10	 Rezo 15	 Rezo 20	 Rezo 30	 Rezo 50	 Rezo 60	 Rezo 110AW	 Rezo 120AW	 Rezo 140AW	 Rezo 160AW	 Rezo 170AW	 Rezo TLZ 10	 Rezo TLZ 20	
<b>Samsung</b>	CL5/PL10		•												
	Digimax i100		•												
	Digimax i70		•												
	Digimax i8	•	•												
	Digimax i80		•												
	Digimax i85		•												
	Digimax L730		•												
	Digimax L74 Wide				•										
	GX-10 w/compact zoom							•			•				
	GX-1L w/compact zoom							•							
	GX-1X w/compact zoom							•							•
	GX-20 w/compact zoom							•							
	HZ10W/WB500					•					•				
	HZ15W/WB550					•									
	L100/110/200/210	•	•												
	L201/SL201		•												
	L310W		•												
	L73				•										
	L730				•										
	L830				•										
	L83T			•											
	NV100HD				•										
	NV11				•										
	NV24HD				•										
	NV30/NV40	•	•												
	NV4	•	•												
	NV8/10/15/20		•												
	NV9/TL9		•												
	S1060				•										
	S1070			•											
	S630/S730				•										
	S73				•										
	S760/S860				•										
	S85				•										
	S850/S1050				•										
	SC-D382							•							
	SC-HMX10							•							
	SC-HMX20C							•							
	SC-HMX-H100/H106							•							
	SC-HMX-R10					•									
	SC-X105L				•										
	SL102/ES55				•										
	SL201		•												
	SL202/PL50				•										
	SL30/ES15				•										
	SL420/PL60				•										
	SL620/PL65				•										
	SL820/IT100				•										
	ST10		•												
	TL100/ST50					•									
TL320/WB100					•										
TL34HD					•										
VP-D230/D270i							•								
VP-D323/D325i							•			•					
VP-D361i							•								
VPD5000i										•					
VP-D6040i/D6050i										•					
VP-D80i											•				
VP-D907i							•								
VP-D963 WI							•								
VP-D97							•			•					
VP-DX10							•								
VP-HMX10X							•								
VP-W90/VPL700/VPL900											•				
WB500											•				
<b>Sanyo</b>	VPC-C1E Xacti														
	DSC-S5 Xacti			•											
	VPC-C40				•										
	VPC-CA9					•									
	VPC-CG10					•									
	VPC-J4 Xacti			•											
	VPC-TH1						•								
	VPC-WH1						•								
	VPS-FH1						•								
	Xacti CG9						•								
	Xacti DMX-CA8						•								
	Xacti VPC-CA65						•								
	Xacti VPC-CG65						•								
	Xacti VPC-HD1000/HD1010				•						•				
	Xacti VPC-S50														
Xacti VPS-T700	•	•													
Xaxcti VPC-CA6						•									
<b>Sigma</b>	DP-1						•								
	DP-2						•								
	SD-15 w/compact zoom									•					



Rezo 10

Rezo 15

Rezo 20

Rezo 30

Rezo 50

Rezo 60

Rezo 110AW

Rezo 120AW

Rezo 140AW

Rezo 160AW

Rezo 170AW

Rezo TLZ 10

Rezo TLZ 20

Sony	Rezo 10	Rezo 15	Rezo 20	Rezo 30	Rezo 50	Rezo 60	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20
Alpha A230/330/380 w/compact zoom													
Alpha DSLR-A100 w/compact zoom													
Alpha DSLR-A100K w/compact zoom													
Alpha DSLR-A200 w/compact zoom													
Alpha DSLR-A300 w/compact zoom													
Alpha DSLR-A350 w/compact zoom													
Alpha DSLR-A900 w/compact zoom													
DCR-DVD108													
DCR-DVD203E													
DCR-DVD308													
DCR-DVD403E													
DCR-DVD408/508													
DCR-DVD608/708													
DCR-DVD650/850													
DCR-HC28													
DCR-HC38/46/HC48													
DCR-HC47E													
DCR-HC62													
DCR-HC90E/96													
DCR-PC55													
DCR-PC8													
DCR-SR-200/300													
DCR-SR40													
DCR-SR42/SR62/SR82													
DCR-SR47/67/87													
DCR-SX40/41/60													
DCR-TRV138													
DCR-TRV280													
DCR-TRV285E													
DSC-G1													
DSC-G3													
DSC-H10													
DSC-H20													
DSC-H50													
DSC-H7/H9													
DSC-HX1													
DSC-R1													
DSC-S650/S700/S800													
DSC-S730													
DSC-S750/S780													
DSC-S950													
DSC-S980													
DSC-T100													
DSC-T2													
DSC-T20													
DSC-T200													
DSC-T300													
DSC-T500													
DSC-T70													
DSC-T700													
DSC-T777/T770													
DSC-T90/T900													
DSC-W110/W200													
DSC-W115/W125													
DSC-W120/W130													
DSC-W150/W170													
DSC-W210/W220													
DSC-W230/W290													
DSC-W300													
HDR-CX100													
HDR-CX12													
HDR-CX7													
HDR-HC5													
HDR-HC7/HC9													
HDR-SR1													
HDR-SR5/SR7													
HDR-TG1													
HDR-UX1													
HDR-UX10													
HDR-UX5/UX7													
HDR-XR100/200V													
HDR-XR500V/520V													
MHS-CM1													
MHS-PM1													
NSC-GC1													
Thomson													
VMD-160/170													
VMD-270													
Vivitar													
V6320													
Vivicam V6200W													

\*Availability may vary depending on country and location